FITTING INSTRUCTIONS - COASTAL PULL KNOBS





Fixing details for secret fixing method.

- 1. Drill 13mm hole through 2 skins of plastic and 1 skin of steel to the centre of where pull knob is to be located.
- 2. Using an 8mm hex key thread secret fix thread nut into the sash.
- 3. Remove straight through fixing nut from thread bolt and then thread the bolt into the pull knob. (Small amount of grease may be needed).
- 4. Cut thread bolt down to 30mm.
- 5. Put rose onto the pull knob and thread into door sash until pinch tight.













Fixing details for straight through fixing method.

- 1. Drill 8mm hole through 2 skins of plastic and 1 skin of steel then repeat from opposite face of profile ensuring you have measured accurately the hole centres of each side.
- 2. Remove straight through fixing nut from thread bolt and then thread the bolt into the pull knob.
- 3. Push thread bolt through the holes in door sash and cut to length then secure with nut end.

For further assistance, call 01702 613733

www.climatec-windows.co.uk 11-14 Fletchers Square, Temple Farm Industrial Estate, Southend-on-Sea, Essex SS2 5RN